

► **CT6-ST COAX CABLE TESTER**

INSTRUCTIONS

WARNING! ~ Never connect this tester to a live wire. Doing so may damage the tester or the equipment the cable is connected to.

FUNCTION TEST:

- A Press and hold the button switch on the function plate to activate the tester. Only the green LED will be lit to indicate the "open" situation on the end of the connector. This will also indicate that the batteries are active. If the green LED does not light, replace the batteries.
- B Slide the receiver out from the slot of the transmitter. Plug the receiver and transmitter onto each other. Press and hold the switch, the indicators will display an "OK" situation.

OPERATION:

- A To test, slide the receiver from the slot of the transmitter. Plug the receiver and transmitter on each end of the testing coaxial cable. Press and hold the switch; the LED indicator on the transmitter will display the test result as follows:
 - 1 "OK", Two LED's (red and green) will blink alternately.
 - 2 "Short", Two LED's will both light up constantly.
 - 3 "Open", Only the green LED will light up.
- B Relieve the switch to turn off the tester. Slide the receiver back to the slot of the transmitter for storage.

BATTERY REPLACEMENT:

If the LED indicators become weak or sluggish in performance, the batteries should be replaced. The procedure is as follows:

- A Slide the receiver out to locate the battery door on the transmitter side.
- B Slide the battery door and replace with 2-1.5 volts AG13 Button Cell batteries. Observe the correct polarity. The positive port is toward the face of the LED's.
- C Slide the battery door in place.

MADE IN U.S.A.



Coastel Cable Tools International Corp.

1211 South Salina Street
Syracuse, New York 13202 USA
1-315-471-5361 FAX 1-315-472-1765



1-800-451-7615

www.CoastelTools.com

